

Horus User Manual

Revision 0.2

IMPORTANT SAFETY AND INSTALLATION INSTRUCTION

SAVE THESE INSTRUCTIONS

INSTRUCTIONS PERTAINING TO RISK OF FIRE, ELECTRIC SHOCK, OR INJURY TO PERSONS

WARNING – when using electric products, basic precautions should be followed, including the following:

1. Read all of the safety and installations instructions and explanation of graphic symbols before using the product.
2. The product must be grounded. If it should malfunction or breakdown, grounding provides a path of least resistance or electric current to reduce the risk of electric chock. This product is equipped with a power supply cord having an equipment-grounding conductor and a grounding plug. The plug must be plugged into an appropriate outlet which is properly installed and grounded in accordance with all local codes and ordinances.

DANGER – Improper connection of the equipment-grounding can result in a risk of electric shock. Do not modify the plug provided with the product – if it will not fit the outlet have a proper outlet installed by a qualified electrician. Do not use an adapter that defeats the function of the equipment-grounding conductor. If you are in doubt as to whether the product is properly grounded, check with a qualified serviceman or electrician.

3. Do not use this product near water – for example, near a bathtub, washbowl, kitchen sink, in a wet basement, or near a swimming pool, or the like.
4. This product should only be used with a stand or cart that is recommended by the manufacture.
5. This product, either alone or in combination with an amplifier and speakers or headphones, may be capable of producing sound levels that could cause permanent hearing loss. Do not operate at a high volume level or at a level that is uncomfortable. If you experience any hearing loss or ringing in the ears, you should consult an audiologist.
6. The product should be located so that its location or position does not interfere with its proper ventilation.
7. The product should be located away from heat sources such as radiators, heat registers, or other products that produce heat.
8. The product should be connected to a power supply only of the type described in the operating instructions or as marked on the product.
9. The power-supply cord of the product should be unplugged from the outlet when left unused for a long period of time. When unplugging the power supply, do not pull on the cord, but grasp it by the plug.
10. Care should be taken so that objects do not fall and liquids are not spilled into the enclosure

through openings.

11. The product should be serviced by qualified service personnel when: A. The power supply cord or plug has been damaged. Objects have fallen, or liquid has spilled into the product, or C. The product has been exposed to rain, or D. The product does not appear to be operating normally or exhibits a marked change in performance, or E. The product has been dropped, or the enclosure damaged.

12. Do not attempt to service the product beyond that described in the user maintenance instructions. All other servicing should be referred to qualified service personnel.

13. **WARNING** - Do not place objects on the power supply cord, or place the product in a position where anyone could trip over, walk on, or roll anything over cords of any type. Do not allow the product to rest on or be installed over cords of any type. Improper installations of this type create the possibility of a fire hazard and/or personal injury.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

No part of this documentation may reproduced in any form whatsoever or be stored in any data retrieval system without prior written permission of the copyright owners.

This documentation is supplied on an as-is basis. Information contained within this documentation is subject to change at any time without notice and must not be relied upon.

All company and product names are TM or Registered Trademarks ® of their respective owners.

Windows 7 is a trademark of Microsoft Corporation.

Merging Technologies makes no warranties express or implied regarding the Horus embedded software, its quality, performance, merchantability or fitness for a particular purpose. The software is supplied "as is" you, the purchaser, are assuming the entire risk of the results of using this Merging Technologies software.

In no circumstances will Merging Technologies, its owners, directors, officers, employees or agents be liable to you for any consequential, incidental or indirect loss or damages including loss of time, loss of business, loss of profits, loss of data or similar resulting from the use of or inability to use the Merging Technologies hardware and or software or for any defect in the hardware software or documentation.

© Copyright Merging Technologies Inc. 2012. All rights reserved.

IMPORTANT NOTICE:

Please read the following information very carefully before attempting any installation. Failure to comply with the precise instructions may result in damage to your Merging hardware. Please read this entire section of the manual carefully before installation.

STATIC DANGER NOTICE:

Please note that the Horus contains delicate electronic components that can be damaged or even destroyed when exposed to static electricity. Take all necessary precautions not to discharge static electricity when touching any of the Horus connectors.

Product Regulatory Compliance

The Merging Horus Network Converter is designed and tested to meet the standards and regulations listed in the following sections.

Product Safety Compliance

Horus complies with the following safety requirements:

- UL 1950 – CSA 950 (US/Canada).
- EN 60 950 (European Union).
- IEC 60 950 (International).
- CE – Low Voltage Directive (73/23/EEC) (European Limits).
- EMKO-TSE (74-SEC) 207/94 (Nordics).

Product EMC Compliance

The system has been tested and verified to comply with the following EMC regulations:

- FCC (Class A Verification) – Radiated and Conducted Emissions (USA).
- CISPR 22, 3rd Edition (Class A) – Radiated and Conducted Emissions (International).
- EN45022 (Class A) – Radiated and Conducted Emissions (European Union).
- EN45024 (Immunity) (European Union).
- EN6100-3-2 & -3 (Power Harmonics and Fluctuation and Flicker).
- CE – EMC Directive (89/33/EEC) (European Union).

Electromagnetic Compatibility Notices

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference and (2), this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit other than the one to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Any changes or modifications not expressly approved by the grantee of this device could void the user's authority to operate the equipment. The customer is responsible for ensuring compliance of the modified product.

Only peripherals (computer input/output devices, Ethernet switches, terminals, printers, etc.) that comply with FCC Class B limits may be attached to this computer product. Operation with noncompliant peripherals is likely to result in interference to radio and TV reception.

All cables used to connect to peripherals must be shielded and grounded. Operation with cables, connected to peripherals that are not shielded and grounded, may result in interference to radio and TV reception.

Environmental Limits

System Office Environment

Parameter Limits

Operating Temperature +5 degrees C to +45 degrees C with the maximum rate of change not to exceed 10 degrees C per hour.

Non-Operating Temperature -40 degrees C to +70 degrees C

Non-Operating Humidity 95%, non-condensing @ 30 degrees C

Acoustic noise less than 20 dBA (Cooling Mode set to Low, internal temperature 45 degrees C) in a typical office ambient temperature (18-25 degrees C)

Operating Shock No errors with a half sine wave shock of 2G (with 11-millisecond duration).

Package Shock Operational after a free fall, 18 – 24 inch depending on the weight.

ESD 15kV per Merging Environmental Test Specification

Horus Warranty Information

This product is warranted to be free of defects in materials and workmanship for a period of one year from the date of purchase. Merging Technologies, Inc. extends this Limited Warranty to the original purchaser.

In the event of a defect or failure to conform to this Limited warranty, Merging Technologies, Inc. will repair or replace the product without charge within sixty (60) days. In order to make a claim under this limited warranty, the purchaser must notify Merging Technologies, Inc. or their representative in writing, of the product failure. In this limited warranty the customer must upon Merging Technologies, Inc. request, return the product to the place of purchase, or other local designation, for the necessary repairs to be performed. If the consumer is not satisfied with the repair, Merging Technologies, Inc. will have the option to either attempt a further repair, or refund the purchase price.

This warranty does not cover: (1) Products which have been subject to misuse, abuse, accident, physical damage, neglect, exposure to fire, water or excessive changes in the climate or temperature, or operation outside maximum rating. (2) Products on which warranty stickers or product serial numbers have been removed, altered or rendered illegible. (3) The cost of installations, removal or reinstallation. (4) Damages caused to any other products.

Contacting Merging

International Office:
Merging Technologies S.A.
Le Verney 4
CH-1070 Puidoux
Switzerland

Phone: +41 21 946 0444
Fax: +41 21 946 0445

USA:

Merging USA (Independent Audio)
43 Deerfield Road
Portland,
ME 04101-1805
United States of America

Phone: +1 (207) 773 2424
Fax: +1 (207) 773 2422

For all documentation inquiries or suggestions for improvement:

www.merging.com

© 2012 All rights reserved. Merging Technologies and Horus are registered Trademarks of Merging technologies SA.

Product features and specifications are subject to change without notice.

Merging Technologies SA shall not be liable for technical or editorial errors contained herein, nor for incidental or consequential damages resulting from the furnishing, performance or use of this manual.

INTRODUCTION TO HORUS

Modular by Design

Horus was designed to give its users an amazing amount of Audio I/O channels, over all the most deployed formats, while offering an unprecedented level of quality in such a small form factor. Providing as standard 64 channels of MADI and 24 channel of AES- EBU I/O, you may choose to add up to 6 Analog I/O optional modules and one additional MADI extension module to bring the total MADI capacity to 128 channels and thereby create the ultimate audio interface for your studio, whatever the size. Once the Horus is fully loaded with option cards, it is capable of achieving an astonishing 176 inputs and 178 outputs @1FS. There are indeed 2 more output channels than input channels, considering the Stereo Headphone Monitoring.

Route Signal Anywhere

Horus has been designed so that any input can be routed to any amount of outputs as required... at the same time. With comprehensive routing pages accessible both locally on the touchscreen and by remote access using a standard web browser, Horus is your answer to signal flow management in your studio.

Green Built

For environmentally-conscious users, Horus has been meticulously designed in order to keep consumption at an incredible minimum. A fully loaded Horus running all channels of phantom power will only draw about 60W, making it more affordable to run than your kitchen lights.

HORUS Key Features

- Up to 176 inputs and 178 outputs @1FS
- Works from 44.1kHz to 192kHz (Premium up to DXD/DSD256)
- Signal routing from any input to any combination of outputs
- Works as MADI/AES AD/DA for "standard" operation... AND
- Works in Ravenna mode to deliver all I/O through the network
- Front panel touch screen for local access
- Front panel Stereo Headphone monitoring
- Browser-based remote access using any web enabled device
- Dual redundant power supply option
- Modular design for analog and additional Digital I/O
- Near-zero latency from in to out (<1ms)

Ravenna

The Horus has been designed so that the MADI, AES and Analog modules can all feed into or sink from the network over Ravenna streams, providing up to 176 channels of I/O@1FS over a single CAT5e or CAT6 cable to any other Ravenna devices on the network.

The Ravenna connection on the Horus allows for not only audio, but also control and sync information to flow through as well. Send Timecodes, Wordclock and even GPIO directly to the Horus unit over the same network as your audio. The Ravenna port even provides for the remote control access to the configuration and entire routing of the unit itself! Support for: RS-422/LTC/MIDI/GPIO/Video Ref/WCK

Ravenna is a layer3 IP based protocol. In environments where existing networks are already in place, Ravenna subnets can slip right into place with no additional outlay. In laymen's terms, this means that you can connect your Horus to a properly configured network exactly as you would do for your PC or Mac, with no additional technology required.

Ravenna is a "mission critical" protocol, meaning that it has been designed to ensure immensely low jitter rates and latencies (sub-millisecond) and reliably ensures that every single sample gets to where it needs to go without fail. Horus also provides a secondary, redundant Ravenna connection allowing for uninterrupted use, even when a network connection fails.

Refer to the *Ravenna User Guide* and the *MassCore-Ravenna Configuration Guide* for more details

HORUS HARDWARE


FRONT PANEL



BACK PANEL



HORUS UNIT DESCRIPTION



HORUS BASE UNIT

IOC-HORUS Specifications

Case Material	Powder Coated Steel
Front Panel Material	Brushed Aluminum
Weight (excluding redundant PS)	6.5 kg/ 14.4 lbs
Dimensions (2U rack mounting)	483 x 320 x 89 mm
Voltage (AC)	90V–260V, 47–63 Hz
Power Consumption (Max)	< 60 Watts
Front Panel TFT size/resolution	4.3" / 480 x 272 pixels

Headphone Monitor Jacks

Max output Level (Unbalanced)	Load = 300 Ohms +15 dBu
Output Impedance	75 Ω
Dynamic Range (A-weighted, typ)	109 dB
THD+N (1 kHz) @ -2 dBFS	< -100 dB (0.001 %)
Gain Range (software controlled)	-60 dB to +12 dB
Gain Step/Precision	1dB / ± 0.05 dB

Connectors

"Sync" Cable (LTC/Video Ref/MIDI)	D-Sub 15Pin
LTC In & Out (via "Sync" Cable)	Balanced XLR
Video Reference In (via "Sync" Cable)	BNC
MIDI (I/O via "Sync" Cable)	5-Pin DIN
Word Clock Input (Switchable 75 Ω Termination)	BNC, 0.5Vp-p min
Word Clock Output (Zout = 35 Ω)	BNC, 5Vp-p
AES type/pinout	DB-25 (Tascam Dig.)
MADI types (Coaxial / Optical)	BNC / SC
Headphone Jack 1&2	6.3 mm(1/4")/3.5mm
RAVENNA Primary / Secondary (GbE)	RJ45


Software Specifications

RAVENNA MassCore Driver	Pyramix 8.0 or Higher / Win7 32bit
Windows Driver/OS	ASIO 2.2 / Win7 32 or 64bit
Mac Driver/OS	CoreAudio / MacOS 10.6 or higher (Intel)

HORUS OPTIONAL CARDS

IOM-HORUS AD8/AD8P

These remotely controlled Mic/Line Input cards have set a new benchmark in analog circuitry design. Available in models that work up to 192kHz (**AD8**) and DXD/DSD256 (**AD8P**)



HORUS-AD8/AD8P Key Features

- 8 x exceptionally transparent, Swiss designed pre-amplifiers
- Remote/Local switch to Line Level on a per channel basis
- Completely remote accessible for all parameter changes
- Phantom Power/Phase/Low Cut switchable per channel
- Better than 120dB dynamic range

HORUS-AD8/AD8P Specifications

Mic Pre-Amp + ADC

Mic Pre Max Input (Pad On / Pad Off)	+23 dBu / +13 dBu
Input Impedance (Differential)	1.75 kΩ
Dynamic Range (A-weighted, typ) , ref +13 dBu	122 dB
Gain Range (software controlled)	-10 dB to +60 dB
Gain Step/Precision	0.5 dB / ±0.2 dB
THD+N Pre + A/D (20 Hz-20 kHz) @ -2 dBFS (AD8/AD8P)	0.0016 % / 0.001 %
Interchannel Crosstalk @ 1kHz, typ.	-125 dB
EIN @ >40 dB Gain (150Ω Source Impedance, A-weighted, typ)	-128 dBu
Common Mode Rejection Rate @ 1kHz, typ.	75 dB
Phantom Power (Software Switchable Per Channel)	+48V
Phase Reverse (Software Switchable Per Channel)	YES
Low Cut filter (Software Switchable Per Channel)	-12 dB/octave, 80 Hz

Line Input


Max Line Input for 0 dBFS	+24 dBu
Input Impedance (Differential)	6.5 kΩ
Dynamic Range (A-weighted, typ), ref +24 dBu	122 dB
THD+N Line+A/D (20 Hz-20 kHz) @ -10 dBFS, typ.	-106 dB (0.0005%)
Interchannel Crosstalk @ 1kHz, typ.	-125 dB
Sensitivity Range for 0 dBFS (software controlled)	+4 dBu to +24 dBu
Gain Step/Precision	0.5 dB / ±0.2 dB
Common Mode Rejection Rate @ 1kHz, typ.	75 dB
Connector Pinout	DB-25 (Tascam Ana.)

HORUS-AD8/AD8P Mic-Pre Analog Section

Frequency response +0/-0.5 dB, Line	5 Hz - 75 kHz
Frequency response +0/-2.0 dB, Line	2.5 Hz - 150 kHz
Frequency response +0/-0.5 dB, Mic	10 Hz - 100 kHz
Frequency response +0/-2.0 dB, Mic	5 Hz - 200 kHz
THD+N (1 kHz), Line/Mic at G=0dB	<-115 dB (0.00018 %)
THD+N (20 Hz-20 kHz) , Line/Mic at G=0dB	<-112 dB (0.00025 %)
Interchannel Crosstalk @ 1kHz, typ.	-135dB
5° low-end in-channel Ø deviation pt: Line	13 Hz
5° low-end in-channel Ø deviation pt: Mic	35 Hz
Interchannel phase 10 Hz - 100 kHz	< ±0.1°

IOM-HORUS DA8/DA8P

The **DA8** (up to 192kHz) and the **DA8P** (up to DSD) have consistently shown in testing to be the quietest multichannel D/A conversion modules available anywhere.



IOM-HORUS-DA8/DA8P Key Features

- Auto-mute circuitry for “no-pop” power cycling
- Digitally controlled trims for line up procedures
- Dynamic range of 127dB (typ.)
- Easy to set dip switches for international operating levels

IOM-HORUS-DA8/DA8P Specifications

Max Line Output @ 0 dBFS (jumpers on +24 dBu)	+24 dBu +0/-0.5 dB
Frequency response +0/-0.3dB @ fs = 48000 Hz	6 Hz – 20 kHz
Frequency response +0/-0.3dB @ fs = 2.8224 MHz (DSD)	NA / 6 Hz – 20 kHz
Frequency response +0/-3.0dB @ fs = 2.8224 MHz (DSD)	NA / 2 Hz – 50 kHz
Line Output Impedance (Differential)	100 Ω
Dynamic Range (A-weighted, typ)	126 dB
THD+N D/A (1 kHz) @ 0 dBFS (IOM-HORUS-DA8)	< -113dB (0.00022 %)
THD+N D/A (1 kHz) @ 0 dBFS (IOM-HORUS-DA8P)	< -115dB (0.00018 %)
Interchannel Crosstalk @ 1kHz, typ.	-135 dB
Connector Pinout	DB-25 (Tascam Ana.)


Line Output Level calibration

The DA8 and DA8P modules feature both a hardware level settings in the form a 4 DIP switches per output channel and a software fine adjustment to align the Analog Output levels to whatever local/organization operational levels are mandating.


The Hardware settings are usually to be set only once, at product installation, and only if the desired Operating Line Level defers from the default ex-factory settings of +18 dBu for 0 dBFS.

Procedure for Hardware alignment:

1. Shut down your Horus and make sure that the Horus back panel Power is also switched OFF.
2. Unscrew all DA8 modules that need adjustment.
3. Pull gently out (5-7 cm is enough) to access the DIP Switches there is one block of 4 dip switches per channel. Channel 1 is labeled S1, channel 8 is labeled S8.




4. Set the DIP Switches as per table Legend indicated on the DA8 module card



		Output Level (dBu)			
		+24	+18	+15	+12
Switch S1 to S8	1			ON	ON
	2		ON		ON
	3		ON		ON
	4			ON	ON

Output Level calibration Example:

Assume your operating Level is 21 dBu for 0 dBFS (typical of French Radio Broadcasters), you should set the DIP Switches all OFF (DIP Switch positioned to the left, with respect to the picture below) to set maximum Output Level to +24 dBu (since there is no 21 dBu hardware settings)




Once this is set and the DA modules are screwed back in place. Power up the Horus and go to the Horus Setup Page>Module, select each D/A module for software calibration.

In this example case set the software attenuation to - 3 dB (see image below), so the overall result ends up at 21 dBu for a Full Scale signal



IOM-HORUS-MADM/MADS

The MADI Expansion card (**MADM** - Multimode / **MADS** - Singlemode) doubles the total MADI channel count to 128 inputs and 128 outputs @1FS



HORUS-MADM/MADS Features

- MADI Optical and Coaxial inputs and outputs
- Additional 64 discrete channels of digital input and output (extended mode) at 1FS for a total of 128 inputs and outputs combined with the base unit MADI
- Up to 384 kHz sampling rate as well as DSD 2.8 MHz
- 24-bit resolution
- Fully compliant MADI (AES 10-1991)


HORUS-RSGP

For installations where extended control is needed, Horus owners can add 8xGPIO and RS-422 (Sony 9pin) connectivity with this easy to install option

HORUS CABLES

Connecting the analog audio Input cables to the AD8/AD8P modules

The AD/AD8(P) modules connect the Mic/Line Inputs using DB25 D-SUB connections. Please ensure that the cables you have chosen to use, or have had made, conform to this specification before you attempt to connect them.



Specifications

- Part: CON-D25-XLRF
- Cable Color: black
- Numbered XLR fan-out
- Cable Ø: 12 mm
- Cable Length: 1,5 m
- Cable Weight: 500 gr

In 1	In 2	In 3	In 4	In 5	In 6	In 7	In 8
Pin 24= (+) Pin 12= (-)	Pin 10= (+) Pin 23= (-)	Pin 21= (+) Pin 9= (-)	Pin 7= (+) Pin 20= (-)	Pin 18= (+) Pin 6= (-)	Pin 4= (+) Pin 17= (-)	Pin 15= (+) Pin 3= (-)	Pin 1= (+) Pin 14= (-)
GND is connected to Pins: 2, 5, 8, 11, 16, 19, 22, 25. Pin 13 is not connected							

To connect the DSUB connection to the IOC-AD8(P), line the Male cable up with the female DSUB port on the module. Then, with slight pressure, guide the connector into place. If your DSUB connector has mounting screws on either side, then fasten them to finger-tightness once the cable has been pushed into place.

Note: The pinout of the DB-25 is as per Tascam Analog.


** THESE CONNECTIONS ARE NOT MEANT TO HOLD ANY SIGNIFICANT WEIGHT.**

Ensure that there is no strain from the connected cable as any significant pressure to the module's DSUB connector could damage the Horus unit.

Connecting the analogue outputs cables to the DA8/DA8P modules

The IOC-DA8(P) modules connect the line outputs using DB25 D-SUB connections.

Please ensure that the cables you have chosen to use, or have had made, conform to this specification before you attempt to connect them.



Specifications

- Part: CON-D25-XLRM
- Cable Color: black
- Numbered XLR fan-out
- Cable Ø: 12 mm
- Cable Length: 1,5 m
- Cable Weight: 500 gr

Out 1	Out 2	Out 3	Out 4	Out 5	Out 6	Out 7	Out 8
Pin 24= (+) Pin 12= (-)	Pin 10= (+) Pin 23= (-)	Pin 21= (+) Pin 9= (-)	Pin 7= (+) Pin 20= (-)	Pin 18= (+) Pin 6= (-)	Pin 4= (+) Pin 17= (-)	Pin 15= (+) Pin 3= (-)	Pin 1= (+) Pin 14= (-)
GND is connected to Pins: 2, 5, 8, 11, 16, 19, 22, 25. Pin 13 is not connected							

To connect the DSUB connection to the IOC-DA8(P), line the Male cable up with the female DSUB port on the module. Then, with slight pressure, guide the connector into place. If your DSUB connector has mounting screws on either side, then fasten them to finger-tightness once the cable has been pushed into place.

Note: The pinout of the DB-25 is as per Tascam Analog.


** THESE CONNECTIONS ARE NOT MEANT TO HOLD ANY SIGNIFICANT WEIGHT.**

Ensure that there is no strain from the connected cable as any significant pressure to the module's DSUB connector could damage the Horus unit.

Connecting the AES-EBU cable

The AES ports connect the AES-EBU I/O using DB25 D-SUB connections.

Please ensure that the cables you have chosen to use, or have had made, conform to this specification before you attempt to connect them.



Specifications

- Part: CON-D25-XLRD
- 192 kHz ready
- Cable Color: black
- Impedance: 110 Ohm
- Numbered XLR fan-out
- Cable Ø: 12 mm
- Cable Length: 1,5 m
- Cable Weight: 500 gr

AES In 1 (1/2)	AES In 2 (3/4)	AES In 3 (5/6)	AES In 4 (7/8)	AES Out (1/2)	AES Out (3/4)	AES Out (5/6)	AES Out (7/8)
Pin 24= (+) Pin 12= (-)	Pin 10= (+) Pin 23= (-)	Pin 21= (+) Pin 9= (-)	Pin 7= (+) Pin 20= (-)	Pin 18= (+) Pin 6= (-)	Pin 4= (+) Pin 17= (-)	Pin 15= (+) Pin 3= (-)	Pin 1= (+) Pin 14= (-)
GND is connected to Pins: 2, 5, 8, 11, 16, 19, 22, 25. Pin 13 is not connected							

To connect the DSUB connection to the AES port, line the Male cable up with the female DSUB port on the module. Then, with slight pressure, guide the connector into place. If your DSUB connector has mounting screws on either side, then fasten them to finger-tightness once the cable has been pushed into place.


Note: The pinout of the DB-25 is as per Tascam Digital.

** THESE CONNECTIONS ARE NOT MEANT TO HOLD ANY SIGNIFICANT WEIGHT.**


Ensure that there is no strain from the connected cable as any significant pressure to the module's DSUB connector could damage the Horus unit.

Connecting the MADI cable

The MADI port (both the standard one and the optional MADI Expansion module) can be connected using either Optical or coaxial cabling.




When using Optical cabling, first ensure that you have a clean work area, as dust and debris can affect the connection if any obstruction is present in the connection. Remove the cap on both the cable and the port and slowly / firmly push the cable into the receiving port on the Horus unit until it clicks into place.



Coaxial connector. Slowly bring the Male cable up to the female port, ensuring the centre of the male cable lines up with the slot in the female port. Push the connector firmly into place and twist the sleeve clockwise until it clicks into its locked position.


Connecting the Wordclock input/output




The Wordclock connections on the rear of the Horus unit are coaxial BNC's. To connect a wordclock source from an external device slowly bring the Male cable up to the female port, ensuring that the pin in the centre of the male cable lines up with the slot in the female port. Push the connector firmly into place and twist the sleeve clockwise until it clicks into its locked position.

Connecting the Sync Cable

The Sync Cable (optional with each Horus unit) is a DB15 cable that connects to the "SYNC" port on the rear of the Horus unit. The SYNC cable provides connectivity for MIDI, LTC and Video Reference Input and Output for the Horus unit. To fix this cable to the Horus unit, line the Male cable up with the female DSUB port on the module. Then, with slight pressure, guide the connector into place. Then, once the cable has been pushed into place, use the mounting screws on either side and fasten them to finger-tightness.



Connecting the Ravenna Ethernet cables



The RAVENNA port (Primary and Secondary) are RJ45 female ports. Simply take the RJ45 cable, line it up with the slot on the rear of the Horus unit and slide it into place until it clicks into its locked position.

Connecting the GPIO

Under development

HORUS KEY FEATURES

Modular analogue interfacing

Horus allows the user to choose how many Analogue inputs and Analogue outputs are needed for each unit. Horus provides a total of six universal I/O slots that can accept a combination of Mic/Line modules, and Line output cards. Users can configure their Horus with any combination of them, but installing more than 3 Mic/Line modules requires to install the Horus Redundant Power option. For instance, in a studio environment, 24 A/D (3X IOC-AD8/P) and 8 D/A (IOC-AD8/P) will allow for 24 inputs from the live room and 8 outputs to feed studio monitoring and foldback to the artist. But, with any combination being possible, this is but one of many reasons for different combinations.

Modular Device connectivity

Any of the modules listed below (A/D, D/A, MADI, AES, Ravenna) can be interconnected in any way the user chooses. Simple and easy routing pages allow the user to get signal from any module, and send it to any other combination of modules. An A/D Module could feed 8 Channels of AES Outputs. At the same time, it could feed in 8 channels of the MADI, or even the RAVENNA stream as well. This is the function that allows the user to function with the Horus in either a standalone (Analogue to MADI/AES AD/DA) or in RAVENNA Mode, which connects the audio to a Ravenna network (described below).

With such a wealth of different outputs, it made sense to apply a “route to” instead of a “route from” philosophy in the way Horus presents its routing pages. After an initial training period, you will understand that this is a much more efficient way to present so many routing options in an easy to unfold process. So always ask yourself first which output is being considered and then decide what input signal will feed that output and you will be offered all logical and valid choices at every step. It also made sense to limit the granularity of routing options to blocks of 8 channels, as a good compromise between flexibility and complexity.

AD8 / AD8P Remote controlled Mic/Line A/D module

The AD8 (works up to 192 kHz) and the AD8P (works up to DXD/DSD256) are remote controllable, extremely high-quality, Microphone pre-amplifiers with a switch on each channel to pass the signal through dedicated line level circuitry instead. The remote control is achieved over Ethernet cable, through the Ravenna Port at the back of the chassis. With all standard analogue controls being available via remote as well (Phantom power on a “per channel” basis, phase invert, HPF) and a Gain stage reaching from -10dB right up to +60dB, these modules are not only easy to use, but absolutely transparent to hear as well.

DA8 / DA8P Safety Conscious Analogue Line output Modules

The DA8 (works at sample rates up to 192 kHz) and DA8P (works at sample rates up to DSD) are specially designed with the user's speakers in mind. Incorporating analogue mute circuitry, the DA8/P modules provide protection against spurious transients that may occur during Sample rate changes, and power cycling “clicks” and “pops” which can damage not only speakers, but also the ears of the listener. When you add to that a noise floor of less than -125dB, these are the ultimate analogue output for any monitoring system.

Redundant power supply option

In broadcast and live applications, nothing is allowed to fail. By requesting the addition of the optional redundant power supply to be configured with your Horus interface, you can prevent against the possibility of a power supply failure. The redundant power supply takes up no more room and only adds a few grams to the unit's total weight.

MADI 1

This MADI port (switchable between coaxial or optical input connections using the front panel Touch Screen) provides users with up to 64 MADI I/O for use with the system. The signal being sent to the MADI Outputs (both Coaxial and Optical available simultaneously) are configurable in blocks of 8 channels and can be from any other module in the Horus.

MADI 2 (Expansion Slot)

An expansion slot allowing for a second MADI card to be fitted into the Chassis, bringing the total MADI I/O up to 128 channels. When using the RAVENNA connection to deliver sound to your Pyramix or Ovation system, this increases the total possible Inputs and outputs in a single Pyramix/Horus combination to a mind-blowing 176 x 178 channels (combined Analogue/AES/MADI).

AES-EBU

Coming as standard (as the MADI 1 module) are 3 x D-SUB25 connectors providing 24 channels (12 AES pairs) of AES-EBU I/O.

Signal routing paradigm

Horus is quite possibly the most flexible audio interface ever designed. Users can literally route any input signal to any output module. Better yet, it can route any input signal to any combination of output modules. Routable in blocks of 8 channels, a user can send 8 Mic Inputs to 8 AES outputs. At the same time the user can also send it through the MADI outputs and into the RAVENNA stream.

RAVENNA IP Audio

Using RAVENNA IP audio, Horus can connect to a standard network, using off the shelf switches and other IT technology to become a node on a LAN. From that point, any other RAVENNA node can receive information from and deliver information to, any combination of RAVENNA devices on the network. It is a revolution in Audio technology and will soon mean the end to costly audio routers and matrices and allow any facility an immense amount of flexibility. From Broadcast and TV/Film post-production, to music, live events, theatres, cruise ships and many more applications, the RAVENNA Enabled Horus interface will reinvent how systems come together.

Synchronization and Control information

Audio is not the only information that can pass down the Ravenna connection. Horus is able to send sync and control information such as LTC/MIDI/RS-422 and GPIO down the same wire to and from the Horus unit.

Key Specifications

Please see the sections below for the measurement performed on the circuitry inside the Horus unit.

Installing additional Horus I/O Module

Installing additional Horus I/O Cards (AD8/AD8P or DA8/DA8P)

Before you get started

- Place your Horus unit on a hard and dry surface or mount it onto a 19" rack, and leave plenty of room for air convection.
- In order to meet the EMC requirements of directives 89/336/EEC and 93/68/EEC, and in order to obtain the high performance possible for the Horus unit, you must use correctly shielded cables of good quality for all external connections when installing the Horus unit. For the power connection, a normal unshielded power cable with a proper ground can be used.
- Make sure that your sound system is at a safe volume level.


Hardware Installation

This section will take you through installation of your Horus unit. We will describe how to mount the I/O modules and the power, audio and digital cable connections that can be accessed on the rear panel.

PLEASE ENSURE THAT YOUR HORUS UNIT IS SWITCHED OFF BEFORE ATTEMPTING TO CONNECT ANY CABLES TO THE UNIT.

If you need to mount an I/O module at a later stage, the following procedure is used.

1. Place the shutdown Horus unit on a dry steady horizontal surface. Remove all cables (including the power cable).
2. On the back of the Horus unit there are 6 slots for mounting the Analogue I/O cards. While all 6 slots are internally equivalent, the 3 top slots are preferably for the AD8 or AD8P Mic/Line input modules and the lower 3 for the DA8 or DA8P line output modules. On the drawing above, they are marked as blind Plates for I/O module slots.
3. To remove blind plates for I/O module slots, remove the 2 screws on each side of the plate. Use a Phillips (cruciform) screwdriver tool size 2
4. Only remove the number of blind plates necessary to fit the I/O module(s). If only one I/O slot is installed, remove only 1 blind plate. If 2 I/O slots are installed, remove 2 blind plates.
5. It is very important to insert the I/O card horizontally and carefully into the Horus unit. There are 6 set of guides inside the Horus unit to guide the I/O cards correctly into place. Do not in any way use force to insert the I/O card. This may damage the card. Slide card slowly as picture below shows.



6. When the cover plate of the I/O card covers the hole created by removing the blind plate, the 2 screws from the blind plate are mounted in the sides of the I/O card. Tighten the screws carefully and be careful not to damage the threads.
7. After inserting the I/O module, the Horus unit might need to be initialized. If this is the case, please follow the instructions received with the I/O module.

Installing additional Horus MADI Extension Module (MADM or MADS)

Before you get started

- Place your Horus unit on a hard and dry surface or mount it onto a 19" rack, and leave plenty of room for air convection.
- In order to meet the EMC requirements of directives 89/336/EEC and 93/68/EEC, and in order to obtain the high performance possible for the Horus unit, you must use correctly shielded cables of good quality for all external connections when installing the Horus unit. For the power connection, a normal unshielded power cable with a proper ground can be used.
- Make sure that your sound system is at a safe volume level.


Hardware Installation

This section will take you through installation of your Horus unit. We will describe how to mount the I/O modules and the power, audio and digital cable connections that can be accessed on the rear panel.

PLEASE ENSURE THAT YOUR HORUS UNIT IS SWITCHED OFF BEFORE ATTEMPTING TO CONNECT ANY CABLES TO THE UNIT.

Installing Horus MADI Extension I/O procedure

The MADI extension packaging should include the MADI module along with; two BNC nuts, two spacers and two screws.




1. Place the shutdown Horus unit on a dry steady horizontal surface. Remove all cables (including the power cable) and unscrew the Horus top panel.
2. On the Back Panel unscrew the MADI cover plate above your current MADI 1 I/O Module



Unscrewed MADI cover plate




3. Open the Horus top panel, remove the AD8/AD8P or D/A8/DA8P modules that could be obstructing the MADl module access
4. Disconnect the ribbon cable carefully




5. Screw the 2 spacers onto the MADl 1 / AES board



6. Carefully slide the MADl extension board so that the output connectors come out of the Horus back panel. You will need to do so with an angle that should allow you to push and fit into the header of the MADl 1 card (below). Align and push gently the MADl extension board so that it fits in the header.



7. Screw the MADI extension using the 2 screws received




8. Fix back the Ribbon cable
9. Screw the 2 BNC nuts at the back of the Horus MADI Extension I/O BNC connectors



10. Put back the modules that were taken out
11. Close and screw back the Horus top panel cover
12. Power back on the HORUS and you should now see the MADI 2 module present

Installing the Merging PCIe Ethernet Controller Card NET-MSC-GBEX1

Detailed steps on how to fit the NET-MSC-GBEX1 PCIe card in your PC machine.




1. Power down your PC and switch it off at the wall. Remove the screws holding the top or sides of the case on and carefully slide off the panel.



2. Wearing an anti-static wristband is preferable whenever working with sensitive electrical equipment. Keeping one hand on a metal part of the case will have the same effect, though you may need both hands when installing certain items of hardware.

3. Locate an empty PCIe slot and remove the metal backing plate by removing the screw holding it in place and carefully sliding it up and out. In some cases, there are no backing plates and you will need to remove a length of metal instead. Do this using a flat-blade screwdriver and/or pliers, taking care to avoid any sharp edges left behind.

4. Next, remove the NET-MSC-GBEX1 card from its envelop bag and line it up with the vacant PCIe slot as shown below.



5. Push down gently at first, ensuring you have the pins lined up correctly with the slot, and then apply more force to slot the card home.
6. Replace the screw holding the backing plate in place and check that the card sits securely. Finally, replace the sides of your case and plug your machine back in.
6. At "First Power Up" Windows will discover the Merging Ethernet PCIe card

Note: Refer to the MassCore-Ravenna Configuration Guide for more details on the Pyramix MassCore-Ravenna setup

Horus Power On


Connecting the Power Cable

The Horus unit runs on 85-240 V, 50-60 Hz AC voltage. Excessive voltages can seriously damage the Horus unit, so make sure that your AC power matches the voltage of your Horus unit. When you connect the power use the cable you received together with your Horus unit and plug it into a grounded outlet.


For safety and EMC reasons, and to prevent audio hum, the system must be properly grounded. If your power source does not have a standard three-hole socket, the system must be grounded in another appropriate manner.

If your Horus unit is equipped with the Redundant Power Supply option, make sure you connect both mains cables (one to PRI and one to SEC mains plugs on the Horus).

1. Ignite the Horus Back Panel Power Switch




2. Press the Horus Front Panel Power Button



3. The Horus front panel button will turn blue. If the panel button light isn't steady but appears to flicker, this may indicate a faulty condition and requires immediate shut down.
4. Wait until the Horus is fully started and displaying the Main Home screen.


HORUS TOUCH SCREEN CONTROL INTERFACE

Horus Menu Hierarchy




Main Home Screen

This is the screen which you will see after the Horus completes its boot sequence. From here you can get to all the other menus for the setup and use of the Horus. If at any time you want to return to the Main Screen, you can press the Merging Logo in the bottom left-hand corner to come back out to the Main Screen. The screen also has access to the 5 main sections of the Horus menu: **Monitor**, **Meters**, **IO & Sync**, **PreAmp** and **Setup**.



Monitor Menu


The Monitor menu refers to the Horus front panel Headphones Monitor jacks. The Headphone jack 1&2 (6.3 mm and 3.5 mm) will output the same level and source.



- | | |
|-----------------|---|
| Headphone gain: | Sets the gain of the Headphone output. Use the slider (Left= less gain / Right= more gain) or the + - buttons to set the gain to the desired level
Headphone level range: -60 dB to +12 dB |
| Headphone Mute: | Mutes the headphone output when OFF is active |
| Output Source: | Shortcut to the Output Source Page for the Monitor module (Described below in "Modules Sub-Menus section") |

IO & Sync Menu


The IO and Synchronization menu is where the user can select the source of the Horus reference clock. It is essential that these settings are configured correctly in order to ensure a clean audio signal through the Horus unit.



Reference Source	Choose which sync source is desired by pressing on the respective Reference source. Available Reference Sources are: MADI, Sync or AES
Reference navigation	Selecting a Reference with multiple choices (such as Sync or AES) will enable the source navigation. The navigation is performed from top to bottom and will cycle through in such order at each consecutive pressing. The selection of another Reference Source will re-select the top entry by default.
PTP Clock	<p>The Precision Time Protocol (PTP) is a protocol used to synchronize clocks throughout a computer network. Also known under IEEE 1588, it is a protocol designed to synchronize real-time clocks in the nodes of a distributed system that communicate using a network. Ravenna is based on and uses V2 of this IEEE standardized protocol. PTP Clocks allow for a time resolution down to the Nanosecond.</p> <p>Master: indicates that the current Horus is the PTP Master Slave: The Horus is slave to another PTP Master</p> <p>The Horus will always try to be the PTP Master. If multiple Horus are used in a network environment, the Horus set in this order will have the PTP Master priority, using the Best Master Clock Algorithm (BMCA):</p> <ol style="list-style-type: none"> 1. Video sync 2. Word Clock 3. AES 4. MADI 5. Internal 6. Ravenna (always slave unless there is no PTP master available)
Sync Colour table:	<ul style="list-style-type: none"> ■ Dark Blue: Signal present ■ Light Blue : Signal valid ■ Black: No Signal ■ Red: Unlocked ■ Yellow: Locking ■ Green: Locked

REFS Menu (I/O & Sync)

This Sub Page menu is where you can visualize the Deviation and Jitter of the External Reference, as measured by the Horus synchronization circuitry.



Frequency: The long-term measured Frequency (in Hz) and deviation in ppm (parts per million) between the signal the unit is locked on and the internal reference.


Delta: The short-term (instantaneous) time offset between the reference signal and the internal (considered as ideal) reference, measured in nanoseconds (ns).

Meters Menu

The Meters menu is non-active as it is not yet implemented

PreAmp Menu


The PREAMP (A/D) menu becomes active if you have 1 or more AD8(P) modules installed in the Horus unit, allowing full access to the Input controls. Please see below for a description of the buttons available.



All	<p>Active: Will select all 8 input channels for function and level grouping</p> <p>Non-active: Users can adjust the input settings and level for the selected channel only</p>
Gain	<p>When in Mic, the input level range allows setting the Mic Preamplifier's Gain from -10.0 dB to +60.0 dB. In the range from -10 to 0 dB, a 10 dB Pad is actually inserted.</p> <p>When in Line, the input level range allows the Line Input Sensitivity to be adjusted from +24 dBu down to + 4 dBu for 0 dBFS.</p> <p>The – or + button enables dec/increments of 0.5 dB steps</p> <p>Padding: a 10 dB Pad is automatically inserted in the Mic Preamp circuitry as soon as the Gain is set to lower than 0 dB, without having to press a dedicated Pad button. See the HORUS Web Control access under PreAmps page for visual scaling details.</p>
Mic or Line	Switches the Input from the Mic-Pre amplifier to the line level circuitry. The button will show the current input signal path it is set for (Mic or Line)
48V	This button will turn on 48V phantom power for the channel. If it is lit, it means that Phantom power is active. Only active on channels set to Mic.
Ø	Phase invert button. When lit, this inverts the polarity of the considered input signal.
80 Hz	Low cut filter 80 Hz. Second order, 12 dB/octave.
Navigation	Use the side left << and right >> arrows in order to navigate through banks of 8 inputs. Will only be active if more than one AD8(P) module is present in the unit.

SETUP MENU


The Setup menu's primary page contains function buttons described below as well as sub-menu links listed in the sub-sections; **Formats**, **Routing**, **Modules** and **Network**.



System Info (Set Up):

In this sub menu you will find details on the Horus internals; current consumption, voltage, temperature, fan speed, serial number and the firmware version currently installed.


	Current [mA]	Primary [V]	Secondary
+15V	310	+16.41	+12.04
+5V	1060	+5.45	+2.62
-15V	268	-15.02	-9.96
+48V	0	+47.71	
Temperature	37 [°C]		
Fan speed	1834 [rpm]		
Serial Numbers:	H80028, ET80028, MA80028		
Firmware Version:	253 (25.04.2012)		


< SETUP

Backlight:	Dim active will darken the Horus display's luminosity. Does in turn also save some power and hence some internally generated heat...
Cooling Mode:	<p>Settings for either Low, Mid or High Cooling. This will affect the speed of fan in reference to the internally measured temperature. While there is no universal preferred setting, we recommend that unless noise levels are a concern, you leave the setting on Mid or High for the coolest operation and best protective results.</p> <p>Low: Fan starts above 45 °C</p> <p>Mid: Fan starts above 35 °C</p> <p>High: Fan always on at lowest speed (less noise), speed starts rising above 25 °C</p>
Terminations:	<p>75Ω for WCK: Sets 75Ω termination for the Wordclock Input. Enabling this will disable the Wordclock output.</p> <p>75Ω for Video: Sets 75Ω termination for the Video reference Input. Unless the Video Reference signal provided to the Horus is daisy-chained to other equipment, you should always terminate your Video signal for most reliable operation.</p>
Shutdown:	Completes a proper shutdown of the Horus unit, including a save of the current configuration. Do not attempt to shutdown the Horus unit in other ways (such as flipping the power switch on the back of the device).
Reboot:	Power cycles the Horus unit (shutdown>Boot up)
Reboot maintenance	Power cycles the Horus unit (shutdown>Boot up) and restarts in Maintenance mode (required mode for Firmware upgrade)
Save Config:	Will save all current settings and parameters of the Horus

Advanced (Set Up):


ASIO/CoreAudio Clock Setting can be set to On or Off



Screensaver: The Horus touch screen screensaver can be set to 15 minutes, 30 minutes, 1 hour or disabled



Formats Menu (Setup)




Sample Rate: Select the Horus Sampling Rate
44.1 kHz - 48 kHz - 88.2 kHz – 176.4 kHz - 192 kHz - DXD - DSD
Note: The available Sampling Rates depend on the Horus Analog modules cards. Only Premium Analog modules offer support beyond 192 kHz.

Frame Rate: TimeCode Frame Rate selector (23.98frm/s, 24frm/s, 25frm/s, 29.97frm/s, 30frm/s)

Video Format: Video Reference Format selection. Offers a choice of PAL, NTSC and a wide variety of TriLevel High-Definition (HD) formats

Modules Menu (Setup)

Module menu will show the available Horus Module that your Horus has in its configuration



Selecting one of the Modules described below will open the Module I/O configuration menu

Monitor

Shortcut to the Monitor page described above.

A/D N

The A/D buttons, which become active if you have 1 or more AD8(P)modules installed in the Horus unit, allow access to the Input controls. N being a number incrementing from 1 to 6 (when looking from the rear of the unit number 1 is left top, 6 is bottom right) referring to which of the six slots the module is being inserted in. Please see below for a description of the buttons available.

D/A N

The D/A buttons become active when 1 or more IOC-DA8(P) modules are installed in the Horus unit.

MADI 1-2


MADI 1 port comes as standard with each Horus. MADI 2 will be listed as “EMPTY” in Horus units that are not fitted with the optional MADI expansion card

AES 1-3

Comes as standard. The AES buttons are active since this module is coming as standard (as the MADI 1 module). Connectivity is over 3 D-SUB25 connectors providing 24 channel (12 AES pairs) of AES-EBU I/O.


Modules: MADI Sub-Menu

MADI 1 port comes as standard with each Horus. MADI 2 will be listed as “EMPTY” in Horus units that are not fitted with the optional MADI expansion card




- Mode:** Sets the MADI mode to either “Standard” (56 audio channels) or “Extended” (64 channels). To determine which setting(s) you are able to use, please consult the user manual of the device you are connecting the Horus to in order to see which (if not both) formats it complies with.
- Physical Mode:** Choose the input signal to be derived from the Coaxial or Optical MADI connections at the back of the Horus unit. You can choose to use either or, but not both at the same time. On the Output side, however, both Coaxial and Optical outputs are always driven in parallel.
- High Speed Frame:** Choose between using Legacy or High-speed frames. For information on why you might want to set this to something other than the default (High-Speed) please consult the user manual of the device you are connecting Horus to.
- Input:** Enabling Visible to Ravenna will allow Ravenna to “see” and use the I/O Connections (seen under the Auto-Connect utility). Use the Auto-Connect utility to activate the I/O stream connections.
- Output Sources:** Users can literally route any input signal to any output module. Users can also route any input signal to any combination of output modules. Routable in blocks of 8 channels.

The example picture below shows a MADI output routing




- Module AES 1: Routed to MADI channels 1 to 8
- Module AES 2: Routed to MADI channels 9 to 16
- Module AES 3: Routed to MADI channels 17 to 24
- Module A/D 1: Routed to MADI channels 25 to 32

Modules: A/D - AES Sub-Menu




Modules: D/A Sub-Menu



Output attenuation:	Calibration of the D/A output (Range -6.0 dB to 0 dB). Refer to the Hardware section for the D/A onboard output level calibration.
Serial Number:	Module serial numbers
Type:	Module Type description
Input:	Enabling Visible to Ravenna will allow Ravenna to see and use the I/O Connections (seen under the Auto-Connect utility). Use the Auto-Connect utility to activate the I/O stream connections
Output Source:	Visual indication of the current Output Source, selection the source will bring you to the Routing Page configuration

Modules: Loopback



Transparency Check: This is a Debug Utility tool that verifies the bits transparency of the audio path
 On: Transparency check enabled
 Off: Loopback mode enabled

Word Length: Word length of the digital audio data signal (16 bits or 24 bits)

Status: Green: Path transparency valid
 Black: Path is not transparent
 Numbering: indicates the number of discontinuity measured

Latency: Output to Input delay in samples

Input: Enabling Visible to Ravenna will allow Ravenna to see and use the I/O Connections (seen under the Auto-Connect utility). Use the Auto-Connect utility to activate the I/O stream connections

Output Source: Shortcut to the Output Source Routing Page configuration

Routing Menu (Setup)

Module routing menu describes where the signal for each module in the Horus is coming from. Each button will go to a sub-menu that allows the user to change the origin of the signal to that specific module. For instance, the Monitor Button in the Routing menu will allow the user to change the routing to the monitor.


Choices are made in blocks of 8 channels (except for the Monitor, which is a Stereo signal).



Monitor:	Brings you to the Monitor Routing configuration page (refer below)
MADI 1:	Brings you to the MADI 1 Routing configuration page (refer below)
MADI 2:	Brings you to the MADI 2 Routing configuration page (refer below)
D/A:	Brings you to the D/A Routing configuration page (refer below)
AES:	Brings you to the AES Routing configuration page (refer below)
A/D:	Disabled as one cannot route TO an Input!
Loopback:	Brings you to the Loopback module (see above)

Routing: Configuration

Monitor - D/A - AES - MADI Routing Output Source (similar)




For all of the output modules (AES 1-3, D/A N, MADI & Monitor Jack) the user can set where the signal feeding it comes from. Any combination is possible using the Output source page linked to any of the output modules.

* All routing in the Horus is currently achieved using banks of 8 channels*

None:	Sets the module so that it does not receive a signal from anywhere. Digital Mute will be output.
Ravenna:	Connects the module to the RAVENNA network and allows any other RAVENNA device to send signal to it.
AES 1-3:	Sets the module being configured to receive signal from any of the 3 banks of 4xAES-EBU input pairs.
MADI 1-2:	Allows the module being configured to receive signal from any 8-channel bank in either of the MADI streams (MADI 2 appears only if the MADI Expansion Card is fitted.)
A/D N:	Sends the signal coming in from the Mic or Line input modules to the output module being configured
Loopback:	Should only be used for test purposes.

Network Menu (Setup)



Device Name:	Name of the Horus unit. This name will be broadcasted across the network and will be seen in applications such as the MT Discovery tool. The Horus unit name can be changed from the Web control access Network page (see section below for all details)
IP Settings:	<i>Manual:</i> Type IP address using box selection and the - or + buttons <i>Auto:</i> The IP address will automatically be generated by the operating system for each network interface
Address:	Set the IP Address for the Horus unit by using box selection and the - or + buttons
Netmask:	Set the Subnet Mask for the Horus unit by using box selection and the < or > buttons
Apply & Reboot:	Once changes have been made to this section, you must press this button to save the settings and power cycle the Horus unit

HORUS Web Control access

Installing and accessing the Horus Control interface remotely

To control and view your Horus remotely with a web browser make sure that you are using one of the Internet browsers below: Google Chrome, Mozilla Firefox, Opera, Apple Safari.

* Microsoft Internet Explorer is not yet supported *

Then take the following steps:


- 1) If you did not install Pyramix v8 proceed from step 2 to 3. If you have already installed a Pyramix v8 go directly to step 4)
- 2) Then download on your system the MTDDiscovery.exe
<http://www.merging.com/horus/download>
- 3) Make sure your Horus is connected to the same network as your PC, and is configured with the correct IP settings (See "Setting up the Horus IP Address")
- 4) Launch the MT Discovery tool (MTDiscovery.exe)

Any Horus devices on the network will be discovered by the MT Discovery tool and will appear in the folder tree under "Ravenna Devices>Horus Devices"

- Double Mouse Clicks on the Horus Device entry will open the Horus Web Interface in your default web browser
- Users can also Right-click on the discovered device and select "Open" and the Horus Web Interface will open in your default web browser.


* Microsoft Internet Explorer is not recommended for this*

Figure 1 MT Discovery Window



Using the Webpage, you can browse the Menus and change parameters in exactly the same manner you can on the front panel TFT of the Horus unit in question.

Figure 2 Horus Web Access




All of the Web access menu pages will be similar to the ones on the Horus TFT display except for the PREAMP and Network menus.

PreAmp web menu

Allows the creation of up to 4 groups

Figure 3 Horus PreAmp Web menu



ALL GRP
RMN GRP
RST GRP
RST ALL GRP
PADING:

Will include all faders into the selected group
Will include the remaining faders into the selected group
Will reset the selected group
Will reset all groups, all grouping will be reset to default
The area where a pad is inserted in the microphone preamplifier signal path is highlighted in light purple.

Network web menu

The Network page allows users to personalize a name for the Horus unit.


Figure4 Horus Network Web menu



The Horus embedded User Manual

Users can open the Horus embedded User Manual by clicking on the ? sign at the bottom left of your browser. This will overlay the Horus User Manual on your Web control access page.


Figure5 Horus Embedded User Manual




HORUS SET UP EXAMPLES

Horus Standalone Converter:


Pyramix & Internal Routing



Pyramix in Live – Stage Box




Pyramix in Live – Technical Rehearsal




Horus Converter with Pyramix V8 & Ravenna


Standard setup




Standalone audio router replacement




Network Audio




Total Redundancy




Live – Total Redundant Stage Box



Concert / Arena / Event – Redundant




Horus with Ravenna Pyramix V8 Native: Live – Mobile Recording




Horus Firmware update procedure

- 1) Download the latest available firmware, available at <http://www.merging.com/horus/download>
- 2) Make sure that the .bin downloaded firmware file on a PC that is on the same network than your Horus. (Users that have received a .rar will first have to Unrar it)
- 3) Power up the Horus using the big power button, while maintaining the small triangle button pressed in order to start in Maintenance Mode



- 4) You can also reboot the Horus in maintenance mode from the Touch Screen Setup menu



- 5) Keep the small button pressed until the yellow caution border display appear on the TFT screen




- 6) Wait until the Horus is fully booted (the progress bar says "Ready")




- 7) Open the MTDDiscovery tool, you should see a device called “Horus in Maintenance Mode”, double click on it.

MT Discovery is installed with Pyramix v8. But it can also be downloaded from Horus Standalone users at <http://www.merging.com/horus/download>



Note: If you do not see the Horus Maintenance Mode entry, try to reboot Horus in Maintenance mode and verify your Horus Ethernet Connection to the MassCore GB Ethernet Card. If you still do not see the Horus maintenance mode under MT Discovery. Open your Windows Device Manager and go under NetWork Adapter. Disable and re-enable the Merging Technologies PCIe Ethernet controller.

Warning: The Horus Maintenance mode is done in Auto IP config. So make sure that you are configured to obtain an IP address automatically when performing a firmware update.



- 8) Your default web browser should open up on a firmware update page



Note: If your web browser does not open on the firmware upgrade page, clear your browser history and re-open the Horus page by Double Clicking on the “Horus in Maintenance Mode” entry in MT Discovery.

- 9) Click on “Select File” and choose the file (.bin) that you have previously unzipped on your disk
- 10) Click on “Update Device” (after a while, you can see some messages on the TFT screen).

Warning: During update do not update your browser (refresh), until the progress is completed, the Firmware update should take from 3 to 5 minutes.
You can see the progress being indicated at the bottom of your Browser Page.

Uploading (15%)... Waiting for 169.254.32.60...

- 11) Wait until the webpage says “Update successful!” or “Update failed*”




The Horus TFT will indicate “Update Done”



- 12) Reboot the Horus by clicking on “Reboot Device”
- 13) Your Horus will then start in normal mode, with the new firmware updated
- 14) You can verify the firmware version installed by going to the Horus Setup menu and selecting System info. The firmware version and date of issue will be displayed.



IMPORTANT: If the Firmware update procedure fails, redo the Firmware update procedure by pressing the “Try Again’ Button (it will bring you back to step 7)



Avoid powering down the HORUS if the firmware update has failed. It is mandatory that you try to re-update the firmware, refresh the online web page if necessary. Or go back to your browser previous page and choose again the firmware and re-update it. If you do not proceed this way your Horus might no longer start up. Then a return to factory might be required.

Contact us at support@merging.com if your firmware update cannot be executed

Horus Troubleshooting

How to provide Merging Support with a debug dump file of the Horus

Dump procedure:

1. Connect the Horus with the Ethernet link to your system
2. Open a web browser (e.g. Google Chrome) and make sure that you type in your Horus Ip address
3. This should open the Main Horus Page (you could also have opened the Horus Web page from the MT Discovery tool)
4. Follow up the ip address with the /debug/syslog as in example below
169.254.60/debug/syslog
5. Mouse+Right click and export the Horus syslog.txt file and send it to us at support@merging.com